

# WHELTAPPERS DCC SOUNDS

## BR Class 158 Function List

F Key	Description	Feature
F0	Marker lights	Directional
F1	Drive sound ON/OFF	
F2	Horn low	
F3	Horn high	
F4	Buffer clash	
F5	Brakes	Toggle on/off CV179 changes intensity
F6	Emergency brakes	Toggle on/off CV180 changes intensity
F7	Doors open/close*	On open/Off close
F8	Right off way buzzers*	On guards signal/drivers acknowledgement
F9	Curve squeal⌘	Speed dependant at low speed
F10	Guards whistle*	
F11	Cab door	
F12	Rail noise⌘	
F13	Cab controls	
F14	Interior Lights	
F15	Cab lights	
F16	Night time running	
F17	Turn off side lights Drive unit	
F18	Turn off side lights Dummy unit	
F19	Shunt mode	
F20	Volume control	
F21	Sanders	
F22	Not used	
F23	Not used	
F24	Not used	
F25	Not used	
F26	Not used	
F27	Not used	
F28	Not used	

\* Does not work when loco is moving.

⌘ Only works when loco is moving.

The feature marked 'Alternate' can play different sounds when pressed to add variety.

Latching means that the sound will come on when the F key is pressed and continue until the F key is pressed again.