

# WHEELTAPPERS DCC SOUNDS

## NER G5 with Autotrailers

F Key	Description	Feature
F0	Lights ON/OFF	If fitted
F1	Drive sound ON/OFF	
F2	Start whistle/ <b>Gong</b> *	
F3	Drive whistle/ <b>Gong</b> ⌘	
F4	<b>Buffer clash/coupling</b> *	Set before stopping
F5	Brakes	CV179 alters intensity
F6	Emergency brakes	CV180 alters intensity
F7	Injector	Latching
F8	One push uncoupling*	
F9	Curve squeal⌘	Latching
F10	Guards whistle? <b>Guards door</b> *	
F11	Wagon buffer clash/ <b>Buzzer stop/bell</b> ⌘	Speed dependant buffer clash
F12	Coal shovelling	Latching
F13	Water filler/ <b>Buzzer start/Bell</b> *	Latching water filler
F14	Safety valve	Latching
F15	Cylinder drain cocks	Speed dependant
F16	Heavy load	
F17	Shunting mode	
F18	Detonators⌘	Alternate
F19	Random sounds OFF	
F20	AUX2	
F21	AWS Bell⌘	
F22	AWS Horn⌘	
F23	<b>Door slams</b> *	Latching
F24	Wheeltapper*	Latching
F25	Not used	
F26	<b>Normal mode turn on</b>	Default 1 Autotrailer/turn on for normal mode
F27	2 Autotrailers	Turn on for 2 Autotrailer mode
F28	Not used	

\* Does not work when loco is moving.

⌘ Only works when loco is moving.

**Works in Autotrailer mode only.**

**Does not work in Autotrailer mode.**