

WHEELTAPPERS DCC SOUNDS

1366 Pannier Version 5 decoder

F Key	Description	Feature
F0	Lights ON/OFF	If fitted
F1	Drive sound ON/OFF	Fade sound while driving
F2	Whistle 1	
F3	Whistle 2	
F4	Buffer clash/coupling*	
F5	Brake application normal	CV179 adjusts braking intensity
F6	Emergency braking	CV180 adjusts braking intensity
F7	Injector	Latching
F8	Automatic uncoupling	
F9	Curve squeal⌘	Speed dependant at low speed
F10	Guards whistle*	
F11	Wagon buffer clash⌘	Speed dependant at low speed
F12	Coal shovelling with AUX1	Latching
F13	Water filler*	Latching
F14	Safety valve	Latching
F15	Cylinder drain cocks	ON/OFF Only works at low speed
F16	Heavy load	Latching
F17	Shunting mode	Switch between light & heavy chuffs
F18	Detonators⌘	Alternate
F19	Turn off stationary random sounds	
F20	AUX2	
F21	AWS Bell⌘	
F22	AWS Horn⌘	
F23	Coach door slams*	Alternate, latching
F24	Wheeltapper*	Latching
F25	Tramway bell	If fitted
F26	Two tone whistle	
F27	Not used	
F28	Not used	
F29	Not used	
F30	Not used	
F31	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.

The feature marked 'Alternate' can play different sounds when pressed to add variety.

Latching means that the sound will come on when the F key is pressed and continue until the F key is pressed again.