

WHEELTAPPERS DCC SOUNDS

BR Class 28 Function Button List 00 Gauge.

F Key	Description	Feature
F0	Lights ON/OFF	
F1	Drive sound ON/OFF	Fade sound while driving
F2	Horn 1	
F3	Horn 2	
F4	Buffer clash/coupling*	
F5	Brake application normal	CV179 adjusts braking intensity
F6	Emergency braking	CV180 adjusts braking intensity
F7	Blower⌘	Latching
F8	Automatic uncoupling	
F9	Curve squeal⌘	Speed dependant at low speed
F10	Guards whistle*	
F11	Wagon buffer clash⌘	Speed dependant at low speed
F12	Radiator fan	Latching
F13	Sanding valve	Latching
F14	Compressor	Latching
F15	Volume control	
F16	Light engine	
F17	Heavy load	
F18	Detonators⌘	Alternate
F19	AUX1	
F20	AUX2	
F21	AWS Bell⌘	
F22	AWS Horn⌘	
F23	Coach door slams*	Alternate, latching
F24	Wheeltapper*	Latching
F25	Not used	
F26	Not used	
F27	Not used	
F28	Not used	
F29	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.

Oil pump off when starting. CV155=0, short pump default CV155=1, Long pump original CV155=2

Start moving delay CV167=15 default setting.