

WHEELTAPPERS DCC SOUNDS

Class 21 & 22 Extended Lights Version 5 Decoders

F Key	Description	Feature
F0	Lights ON/OFF	
F1	Drive sound ON/OFF	Fade sound while driving
F2	Horn 1	
F3	Horn 2	
F4	Buffer clash/coupling*	
F5	Brake application normal	CV179 adjusts braking intensity
F6	Emergency braking	CV180 adjusts braking intensity
F7	Compressor	Latching
F8	Drive hold	
F9	Curve squeal⌘	Speed dependant at low speed
F10	Guards whistle*	
F11	Wagon buffer clash⌘	Speed dependant at low speed
F12	Roof fan	Latching
F13	Sanding valve	Latching
F14	Engine pre start	Then F1 to start engine
F15	One press uncoupling	
F16	Heavy load	Latching
F17	Shunting mode	
F18	Detonators⌘	Alternate
F19	Cab lights	Directional where possible
F20	Train mode	Turns off Reds when pulling a train
F21	AWS Bell⌘	
F22	AWS Horn⌘	
F23	Coach door slams*	Alternate, latching
F24	Wheeltapper*	Latching
F25	Turn off random sounds	
F26	Light engine parking mode	Reds both ends
F27	Not used	
F28	Not used	
F29	Not used	
F30	Not used	
F31	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.

The feature marked 'Alternate' can play different sounds when pressed to add variety.

Latching means that the sound will come on when the F key is pressed and continue until the F key is pressed again.