

WHELTAPPERS DCC SOUNDS

GWR DMU Parcels Normal Functions.

F Key	Description	Feature
F0	Lights ON/OFF	
F1	Drive sound ON/OFF	Fade when moving.
F2	Horn 1 high	
F3	Horn 2 low	
F4	Buffer clash/coupling	Set before stopping
F5	Manual brake ⌘⌘	CV179 adjusts braking intensity
F6	Shunting mode	Set before moving off. STOP when finished.
F7	Not used	
F8	Vacuum buildup*	Latching
F9	Flange/curve squeal⌘	Latching
F10	Not used	
F11	Guard-Driver acknowledgement*	
F12	Sliding door*	On to open/off to close
F13	Cab controls start*	
F14	AWS Bell⌘	
F15	AWS Horn⌘	
F16	Hand brake on*	Normally when engine is not running.
F17	Hand brake off*	Normally when engine is not running.
F18	Vacuum dump*	
F19	Cab light	
F20	Interior light	
F21	Cab controls end*	
F22	Rail clack⌘	Speed dependant
F23	Not used	
F24	Not used	
F25	Not used	
F26	Not used	
F27	Not used	
F28	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.

⌘⌘ Toggle on/off for best effect to slow DMU