

# IRISH RAILWAY DCC SOUNDS

## Class 121/141/181 V5 Sound Decoders Only

F Key	Description	Feature
F0	Side lights	Directional
F1	Sound ON/OFF	Will mute when moving
F2	Horn short	
F3	Horn playable	Latching
F4	Buffer clash/coupling*	
F5	Brakes normal	CV179 adjusts braking intensity
F6	Brakes Emergency	CV180 adjusts braking intensity
F7	Drive hold	
F8	Automatic uncoupling	
F9	Curve squeal⌘	Latching
F10	Guards whistle*	
F11	Wagon buffer clash⌘	Latching
F12	Radio communication	
F13	Station announcement*	CV155= 0-8 Changes station name
F14	Fan	Latching
F15	Push Pull mode	Class 121 IR & IE locos only
F16	Shunting Lights	Class 121 & New MM 141/181 only
F17	Load mode	Default Light Load/ON Light Engine
F18	Load mode	Heavy Load over rides F17 if on
F19	Head Light	Class 121 & New MM 141/181 only
F20	Train Mode	Turns OFF Tail Lights/Class 121/New MM baby GM's
F21	Parking Mode	Turns ON All Reds/Class 121/New MM baby GM's
F22	Wagon Rail Noise⌘	
F23	Coast	
F24	Dual Loco Mode	When coupled to a Class 121/141/181 ***see note***
F25	Rail Clack⌘	
F26	Sanding valve	
F27	Compressor	Latching
F28	Not used	

\* Does not work when loco is moving.

⌘ Only works when loco is moving.

Latching means that the sound will come on when the F key is pressed and continue until the F key is pressed again.

\*\*\*one loco needs to change CV29 from 30 to31\*\*\*