

WHEELTAPPERS DCC SOUNDS

Version 5 decoders LNER J70/GER C53

F Key	Description	Feature
F0	Lights ON/OFF	If fitted
F1	Drive sound ON/OFF	Fade sound while driving
F2	Whistle 1	
F3	Whistle 2	
F4	Buffer clash/coupling*	
F5	Brake application normal	CV179 adjusts braking intensity
F6	Emergency braking	CV180 adjusts braking intensity
F7	Injector	Latching
F8	Automatic uncoupling	
F9	Curve squeal⌘	Speed dependant at low speed
F10	Warning bell	Latching
F11	Wagon buffer clash⌘	Speed dependant at low speed
F12	Coal shovelling with AUX1	Latching
F13	Water filler*	Latching
F14	Safety valve	Latching
F15	Cylinder drain cocks	ON/OFF Only works at low speed
F16	Heavy load	Latching
F17	Tramway speed reduction/shunting mode	Use on tramway & shunting
F18	Detonators⌘	Alternate
F19	Turn off stationary random sounds	
F20	AUX2	
F21	Rail noise	Latching
F22	Not used	
F23	Not used	
F24	Not used	
F25	Not used	
F26	Not used	
F27	Not used	
F28	Not used	
F29	Not used	
F30	Not used	
F31	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.

The feature marked 'Alternate' can play different sounds when pressed to add variety.

Latching means that the sound will come on when the F key is pressed and continue until the F key is pressed again.