

WHEELTAPPERS DCC SOUNDS

S&DR Locomotion V5 Functions.

F Key	Description	Feature
F0	Not used	
F1	Drive sound ON/OFF	
F2	Horn 1 blast	
F3	Horn 2 blast	
F4	Horn 3 blast	
F5	Manual brake	CV179 adjusts braking intensity
F6	Emergency brakes	CV180 adjusts braking intensity
F7	Bell	
F8	Water pump⌘	
F9	Flange/curve squeal⌘	
F10	Guards whistle*	
F11	Not used	
F12	Coal shovelling	
F13	Water fill*	
F14	Safety valve	
F15	Not used	
F16	Cylinder drain cocks⌘	
F17	Not used	
F18	Not used	
F19	Not used	
F20	Not used	
F21	Not used	
F22	Not used	
F23	Not used	
F24	Not used	
F25	Not used	
F26	Not used	
F27	Not used	
F28	Not used	

* Does not work when loco is moving.

⌘ Only works when loco is moving.